

Contents

1. Welcome	1
2. Unpack Your Camera	2
3. Layout and Features	2
Model: FT2	2
4. Indicator Lights	3
5. Download the Faleemi Cloud App	3
6. Account Registration*	4
7. Connect your camera to your Wi-Fi	6
7.1. Connecting the camera to your Wi-Fi Network	7
7.1.1 Setup Option: Wi-Fi connection by QR code (Recommended)	7
7.2.2. Setup Option 2: Wi-Fi connection by Soft-AP	13
8. Main Interface	2C
8.1. Devices Page	2C
ICON Definitions	22
8.2. Alert Page	23
ICON Definitions	23
8.3. Cloud Page	24
ICON Definitions	24
8.4. Me Page	25
ICON Definitions	25
8.5. Multi-View Settings	26
ICON Definitions	26
Add camera to quad screen	27
9. Camera Functions	28
Live Video panel	29
Full screen	30
ICON Definitions	30
9.1. Alert	31
ICON Definitions	33
9.1.1. View alert video	34
9.1.2. Edit alert video (delete or download alert video)	35
9.2. Replay	36
Full screen	37
ICON Definitions	37
9.3. Console	38
9.4. Position	39
a. Set presets	40
b. Name/Delete presets	41

9.5.	. Light	42
	ICON Definitions	42
	Light and night vision settings	43
9.6.	. Device ON/OFF	43
9.5.	. Camera Settings*	45
	9.5.1 Device information	45
	9.5.1.1 Device name	46
	9.5.2. Basic settings	46
	9.5.2.1 Invite family & friends	47
	9.5.2.2 Advanced Settings	48
	9.5.2.2.1 Image rotation	49
	9.5.2.2.2 Intelligent tracking	50
	9.5.2.3 Anti-flicker	50
	9.5.2.2.4 Device microphone	50
	9.5.2.2.5 Mic volume	50
	9.5.2.2.6 Speaker volume	50
	9.5.2.2.7 LED indicator ON/OFF	51
	9.5.2.3 Local application	51
	9.5.2.3.1 Local account	51
	9.5.2.3.2 RTSP	52
	9.5.2.4 Privacy settings	52
	9.5.2.4.1 Camera timed OFF	53
	9.5.2.4.2 Timed OFF schedule	53
	9.5.2.4.3 Device microphone	56
	9.5.2.5 Device time zone	56
	9.5.3. Home protection settings	57
	9.5.3.1 Motion detection	57
	9.5.3.1.1 Detection area	58
	9.5.3.1.2 Sensitivity level	59
	9.5.3.2 Motion alert	60
	9.5.3.2.1 Enable	60
	9.5.3.2.2 Schedule	61
	9.5.3.2.3 Identify and push	63
	9.5.3.2.4 Rich notifications	64
	9.5.3.3 Cloud storage	64
	9.5.3.4 Memory card storage	64
	9.5.3.4.1 Memory card storage	65
	9.5.3.4.2 Schedule	65
	9.5.3.4.3 Storage mode	67
	9.5.3.4.4 Storage space	68
	9.5.3.4.5 Format the memory card	68
	9.5.3.5 Light and night vision	69
9.5.	.4. Device maintenance	70
	9 5 1 1 Network	70

9.5.4.2. Device management	7C
9.5.4.2.1. Restart device	71
9.5.4.2.2. Factory reset	71
9.5.4.2.3. Delete the device	72
10. Alert Page	73
ICON Definitions	73
10.1. View alert video	73
10.2. Edit alert video (delete or download alert video)	75
11. Cloud Page	76
11.1. Basic Plan	77
11.2. Extended Plan	78
11.3. Pro Plan	79
11.4. Plan comparison	8C
11.5. Cloud devices management	80
11.5.1 Add recording devices	80
11.5.2. Camera settings in the enhancement package	81
11.5.2.1. Cloud storage time settings	81
11.5.2.2. Shared users	82
11.5.2.3. Motion alert	82
11.5.2.4. Remove the device from this plan	83
11.6. Cloud Replay	84
12. Me Page	85
ICON Definitions	85
12.1. Album & Message	86
12.1.1. Local Video	86
12.1.2. Local image	87
12.1.3. Download	88
12.1.4. Message	89
12.2. Account security	89
12.2.1. Quick login	9C
12.2.1.1 Auto login	9C
12.2.1.2 Gesture login	9C
12.2.1.3 Touch ID	91
12.2.2. Change Password	91
13.3.2.1. Forgot password? (To reset your account and password):	92
12.2.3. Country/region	
12.2.4. Email	93
12.2.5. Delete Account	
12.3. General settings	
12.3.1. Language	
13.3.2. Reminder of cellular data	
13.3.3. Notification settings	
13.3.4. Enable hard decoding	
12.4 Contact us	9.6

12.5. FAQ	97
12.6. Diagnose	97
12.7. About	
12.8. Sign out	100
13. Frequently Asked Questions (FAQ)	100
1. Which App does this camera use?	100
2. How to reset your camera (restore to factory default)?	101
2. How to install memory card?	101
3. Cannot receive the activated email when you sign up a new account or change ac	count password:
on App	101
4. The memory card cannot be recognized by camera	102
5. What kind of memory card that the cameras are compatible with?	102
6. Why aren't the recorded motion alerts notifying my phone	102
7. I don't have Wi-Fi at my house. Would this camera work without it?	102
8. Can the app be used on two devices at the same time? Like my iPhone and my	family's iPhone.
	102
9. Can you invite someone to the app, and then remove them afterward	103
10. Do I have to subscribe cloud service to use the camera?	103
11. Does the camera need to connect the power supply?	103
12. How can I get after sell service?	103

1. Welcome

Dear Faleemi customer,

We hope that you're fully satisfied with your recent purchase and that it's exceeding your expectations.

If you have any inquiries or require assistance, please don't hesitate to reach out to us.

As a company that's constantly striving for improvement, we're always exploring ways to enhance all facets of our services and products. We welcome any suggestions or feedback you might have, so please feel free to share them with us.

Ensuring your satisfaction remains our utmost priority.

Wishing you a wonderful day ahead!

Warm regards, Your Faleemi Team

Support

For product updates and web support, please visit https://www.faleemi.com/support or contact us by email at support@faleemi.com.

Trademarks

Faleemi and the Faleemi logo are all trademarks or registered trademarks of Faleemi Technologies Ltd. Other trademarks and trade names may be used in this document to refer to either the entities claiming the marks and the names of their products. Faleemi disclaims proprietary interest in the marks and names of others.

Apple®, Apple Store®, iPad®, iPhone®, MAC® (Text, Logo, Picture) are trademarks of Apple, Inc.

Android®, Google Play® (Text, Logo, Picture) are trademarks of Google Inc.

Micro SD® text and logo are the trademark of SD-3C, LLC.


Wi-Fi® is a registered trademark of the Wi-Fi Alliance.

All other products, names or companies are the brands or registered trademarks of their respective owners.

2. Unpack Your Camera


Your package contains the following items.

- 1 x Faleemi FT2 Security Camera
- 1 x Power Adapter
- 1 x Mounting Screws & Plug packs
- 1 x Quick Start Guide



3. Layout and Features

Model: FT2



4. Indicator Lights

There are no indicator lights on this camera.

5. Download the Faleemi Cloud App

Download the Faleemi cloud app. You need this app to set up your Faleemi camera. Go to the app store and search for Faleemi Cloud.

Note: The app works with iOS 8.x and later, and Android 4.0.3 and later.



Faleemi Cloud












Scan to Download






6. Account Registration*


a. Open Faleemi Cloud App, and click Sign up.



b. Enter your email address and create a password. Tick "I have read...", and Click **Next**.




c. Open your email and find the Verification Code. Enter it and continue the setup.



If the verification code does not appear in your email inbox, please check your spam folder or send an email to support@faleemi.com.

d. Click Sign in and enter your password. Click Sign in again.



Note: If you have a Faleemi Cloud account already, simply sign in.

You can enable touch ID for a quick Sign in. If you forget your password, please refer to Forgot password.

7. Connect your camera to your Wi-Fi

IMPORTANT: Before configuring your camera

- Please place the camera close to your Wi-Fi router during setup. You can relocate it to its final location after the setup is complete.
- Please make sure your phone is connected to your 2.4GHz Wi-Fi. (Not your cellular network or 5GHz Wi-Fi).
- The camera ONLY works with 2.4 GHz frequency Wi-Fi. If your router only supports 5GHz, you can purchase Faleemi new model FS2 which works with both 2.4GHz and 5GHz Wi-Fi.
- a. If you are using a Dual Band Wi-Fi Router, and the Wi-Fi names (SSID) for 2.4GHz and 5GHz are different, please make sure that your phone is connected to your 2.4GHz Wi-Fi.
- b. If you are using a Dual Band Wi-Fi Router, and the Wi-Fi name (SSID) for 2.4GHz and 5GHz are the same. Please ignore the 5GHz warning prompt during setup.
- c. If you are unsure if your router supports 2.4GHz Wi-Fi, check the documentation for your Wi-Fi router model number online or Internet service provider (ISP).

7.1. Connecting the camera to your Wi-Fi Network

7.1.1 Setup Option: Wi-Fi connection by QR code (Recommended)

1. Place your camera near your Wi-Fi and power it up with the included adapter.




2. Click [Add device] or +.




3. Click Your Camera Model.




4. Select Wi-Fi connection by QR code mode.



5. Please tick "Make sure..." and Next. If there is no light/tone, please reset the camera. You can find the detailed instructions about how to reset your camera in page 101.




6. Your 2.4Ghz Wi-Fi name will appear. If it doesn't, please turn on your phone Location Services. Enter the correct Wi-Fi password and click Next.




7. The App will pop up a QR code. Please use the camera to scan the QR code by holding the phone in front of the camera at about 4-12 inches. When you hear a tone, please tick "When you..." and click Next.




8. Wait for connection.




9. When you hear "The pairing is successful, you can start using the camera now", the App will move to a page where you can change the camera name (optional), and click OK.



10. The camera will detect the Wi-Fi signal strength of the current location. If the signal is poor, try placing it closer to the router. Click OK.



11. The device will indicate "Online" in the green box. **Congratulations!** Your camera successfully set up. Click the image to view and control it.





You can skip ahead to [8. Main interface] to gain further knowledge about your camera.

7.2.2. Setup Option 2: Wi-Fi connection by Soft-AP

1. Place your camera near your Wi-Fi and power it up with the included adapter.




2. Click [Add device] or +.




3. Click Your Camera Model.




4. Select Wi-Fi connection by Soft-**AP** mode.




5. Please tick "Make sure..." and Next. If there is no light/tone, please reset the camera. *You can find the detailed instructions about how to reset your camera in page <u>103</u>.




6. Click Go to settings.



7. Click on the Wi-Fi hotspot that starts with FAM....



8. Once you have confirmed that you are successfully connected to the Wi-Fi hotspot, tap on <-.




9. Select the name of the 2.4GHz Wi-Fi you need to connect to.




10. Your Wi-Fi name will appear. If it doesn't, please turn on your phone Location Services. Enter the correct Wi-Fi password and click Next.




11. Wait for connection.




12. When you hear "The pairing is successful, you can start using the camera now", the App will move to a page where you can change the camera name (optional), and click OK.



13. The camera will detect the Wi-Fi signal strength of the current location. If the signal is poor, try placing it closer to the router. Click OK.



14. The device will indicate "Online" in the green box. Congratulations! Your camera successfully set up. Click the image to view and control it.




8. Main Interface

When you launch the Faleemi Cloud app, the Devices page displays.

8.1. Devices Page

You can see all the cameras here that you connected to your Faleemi Cloud account.




Icon	Features	Description
@	Devices page	Display devices
	Alert page	Display alerts
\triangle	Cloud page	Display cloud recordings
Я	Me page	Display me
00	Multi-View	You can monitor several cameras (Max.4) on the same screen at the same time
(+)	Add Device	Add new devices
*	Sticky icon	Pin the selected camera to the top
(b)	Play Button	Tap the button to enjoy viewing and controlling of it
Front door	Camera name	You can customize the camera name
Online Offline	Camera status	Display camera connection status
©	Replay	If you set the camera to record alarm videos on SD card or Cloud storage, you can playback the alarm videos from Replay. And you can also tap X1 to set accelerated playback.
©	Camera Settings	For more information, please turn to the Settings page.

8.2. Alert Page

You can see the alerts from all the cameras here.

For more information about the alert settings, see Alert on page 31, motion alert on page 61.



lcon	Description	lcon	Description
<u></u>	Alert	•	New unread alarm events
Nov.06.2020	Date and time	(b)	Play

8.3. Cloud Page

User plays the video recorded on cloud if there is a cloud plan subscribed. We offer the first 30-day for free so you can try the cloud storage service.

View videos anywhere

Videos can be viewed, downloaded and deleted anytime, anywhere, without being lost due to the camera being stolen or damaged.

No worries about capacity

Videos can be saved to the cloud in a loop without limit for 7 days (Basic Plan) or 15 days (Extended Plan) or 30 days (Pro Plan).


Motion detect mechanism

When it detects any motion, it will start to record and keep recording until no more motions detected. You will never miss any important events.

Paid service

You need to subscribe a plan to enjoy the cloud storage, and the new user can get a 30day FREE trial at first time.


For more information, please refer to (11. Cloud Page)



lcon	Features	Description
?	About Cloud Storage	Information about the Cloud Storage.
S	Subscribe cloud	You can try 30-day free trial or subscribe/cancel the
Ţ	Subscribe cloud storage	You can try 30-day free trial or subscribe/cancel cloud storage plan.

8.4. Me Page

Information about Faleemi Cloud account.




Icon	Features	Description
•	Local Video	The alarm videos downloaded from the SD card or Faleemi Cloud App and the video recorded manually can be viewed here. And you can save them to your mobile album.
	Local Photo	The snapped photos can be viewed here. And you can also download the photos to your mobile album.
\searrow	Message	System Messages.

\Diamond	Account security	Set Touch ID or Change Account Password.
0	General settings	Set the Faleemi Cloud app Language and Message notification.
?	Contact us	
②	FAQ	Troubleshooting Frequently Asked Questions
	About	You can check the App version.
ightharpoons	Sign out	Sign out the Faleemi account.

For more information, see Me page on page 86.

8.5. Multi-View Settings




lcon	Features	Description
+	Add	Add camera
4	Back	Back

$ \mathbb{C} $	Dark mode	Dark mode
•	Refresh	When the camera is offline, tap "Refresh", the camera will try to reconnect.
\mathbf{D}	Play/Pause	
8	Delete	Delete camera from the 4 multi-view pages.

Add camera to quad screen


Tap \bigoplus to add the cameras to quad screen.






to go back homepage.

9. Camera Functions



Tap the camera name or the image to enter "Live video panel" page.

Live Video panel



Full screen




lcon	Features	Description
←	Back	Back to the previous page.
©	Camera Settings	For more information, please turn to page 44.
2020-07-04 09:10:22	Camera date	Camera date & time
2K SD	Video resolution	SD: Standard Definition FHD: Full High Definition
1	Full screen	Full screen
८%	Speaker	Speaker On/Off
Q Q	Microphone	Hold to talk
	Record	Record video manually / Recording
	Snapshot	Snapshot


< >>	PTZ Control	Tap the arrow to control PTZ.
+• ••	Console	Console page
[©]	Position	You can set favorite positions to move the camera to the ideal position with a single tap.
<u></u>	Alert page	Display alert
•	Replay	If you set the camera to record alarm videos on SD card or Cloud storage. You can playback the alarm videos from Replay.

9.1. Alert

If you turn on motion alert, it will record 10-sec clips on your Faleemi Cloud App when there is any motion. You can check the alarm videos of the latest two days here for free.

If cloud service is subscribed, you can check the recent 7 days alarm videos. If more than 7 days, please go to Cloud page to replay the alarm video (Extended Plan or Pro Plan).





ICON Definitions

Icon	Description	lcon	Description
<u></u>	Alert	•	New unread alarm events
Nov.06.2020	Calendar	•	Date of recording
	Edit		Speaker On/Off
(b)	Play	①	Pause
	Snapshot	②	Selected



Download

9.1.1. View alert video


M

Tap Calendar to find highlighted (green dot •) dates.

Tap **1** to play alert video in a new page. The

turns green when you are playing the


video. Tap in other videos, it will play the other videos. Tap Calendar to show highlighted (green dot
) dates when there are recordings. Tap on the date, it will show all the motion events of this date.








9.1.2. Edit alert video (delete or download alert video)






9.2. Replay

If you've inserted the memory card (not included) or subscribed the cloud service and turn on Motion detection, the camera will record the alarm videos on the memory card or cloud. You can use the timeline, the calendar to find and view specific recordings.

You can tap or the bottom in first page to go to playback page.



Full screen



ICON Definitions

lcon	Features	Description
X1	Play speed	You can tap 1X, 2X, 4X to fast forward the recorded alarm video.
(b) (ll)	Play/Pause	Tap it to play/ pause the video
(A) (A)	Previous/Next	Tap it to the previous/next video
Snapshot	Snapshot	Capture pictures. You can go to [Me] $ ightarrow$ [Local Photo] to view
oʻʻo	Gridpariot	them and save them in your mobile album.
Mar05.2024	Calendar	Tap a highlighted (green text) date to show up the Timeline.
	Green dot	Date of recordings
04:45 pm	Timeline	Pull the timeline left and right to find and view specific recordings. The green bars show that there are recordings, while gray one indicates that there is no recording.
04:45 pm	Timeline	Tips: pinch-to-zoom adjusts Timeline scale.
Ŵ	Delete	Delete the alarm videos saved on SD card. You can select the fragment that you want to delete or delete the whole day recordings.

₾	Download	Download the alarm videos on SD card to Local Video. Then you can go to [Me] \rightarrow [Local Video] to view them or save them in your mobile album.
②	Help	Useful tips

9.3. Console

Tap the arrow to control PTZ.

Tap the arrow: The camera moves slightly

in the appropriate direction


Press and hold the arrow: The camera moves continuously and fast in the

appropriate direction



9.4. Position


You can set favorite positions to move the camera to the ideal position with a single tap. The position preset allows you to set 4 favorite positions so you can quickly tap one button and it will automatically pan over to that position.



a. Set presets


If you want to add the new position, in Console page and move the camera to

other position, and tap to add the new position.



b. Name/Delete presets


If you want to edit the positions, please go to Position page and tap to edit it.






Give each position a name

Tap , enter the position name in the popped-up window, Tap OK and Done.



Delete Positions

Tap 🗓 to delete the position. Tap Done to confirm it.



9.5. Light

You can turn on/off the spotlight in the page of Light and Night Vision.



ICON Definitions

Icon	Features	Description
*	Light Off	The built-in spotlight has been manually turned off.
*	Light On	The built-in spotlight has been manually turned on.
*	Light Settings	Light and night vision settings.

Light and night vision settings

You can set the mode you prefer to. We recommend "Intelligent Light" mode.

Auto infrared mode

When the light is poor, the infrared lights are automatically used to fill the light to enter the night vision mode. The image is black and white.

Intelligent light


Auto infrared mode works by default, but when amotion occurs at night, the white lights automatically light up and the image becomes color.

Full color night

White light automatically lights up at night, the image remains in color and it automatically goes out during the day.

All off mode

"All off mode", for applications where the light is always bright and the image remains color at all times.




9.6. Device ON/OFF

Turn the camera ON/OFF remotely. If you want to disable the camera temporarily, you can select off. At this time, the camera will not be viewed, it will not record and send the alert, etc. But you can view the previous recorded videos/photos.





Camera on

Camera off



9.5. Camera Settings*






9.5.1 Device information


You can check the camera's Wi-Fi signal, edit device name, check the device ID, Firmware Version, IP Address, Wi-Fi MAC Address.






9.5.1.1 Device name

You can change the device name here.



9.5.2. Basic settings


You can do Basic settings




9.5.2.1 Invite family & friends

Invite: You can invite your family or friends to view the feed of your camera. (You can also stop sharing video on this page)


1.Tap Invite family & friends




2.tap **<**




3. Enter the account you want to share with




4. Permissions of the shared device, tap Save.



5. Invitation succeeded, tap OK



6. Wait for acceptance, tap ... to do the Permissions settings, Reinvite/Delete the invitation.





Accept the sharing on the family/friends Faleemi Cloud App

Please share below instructions to your family members and they will know how to accept this invitation.

Note: Your family/friends should register a Faleemi Cloud account before they can accept your invitation).


1. In your family/friends Faleemi Cloud, it 2. Your family/friends can see the camera will pop up the Device Sharing window, now. tap Receive





9.5.2.2 Advanced Settings


You can do the settings of Image rotation, Intelligent tracking, Antiflicker, Device microphone, Mic volume, Speaker volume and LED indicator ON/OFF.



9.5.2.2.1 Image rotation

You can rotate the image if the camera is installed upside down.

Note: Do not flip unless installed indoors (It will not be waterproof if you install it upside down)



9.5.2.2.2 Intelligent tracking

Switch it on to Enable Intelligent auto tracking



9.5.2.2.3 Anti-flicker

Default AC frequency is 50 or 60Hz. (Adaptive in different regions)

Generally, high-quality LED lighting has no effect on the camera's video picture. However, some old lighting may cause the picture to flicker due to mismatched AC frequency. If your camera video flickers, you can choose another frequency to try.



9.5.2.2.4 Device microphone


If the camera microphone is not working, check to make sure the Camera microphone is enabled






9.5.2.2.5 Mic volume

You can adjust the microphone volume here.



9.5.2.2.6 Speaker volume

You can adjust the speaker volume here.



9.5.2.2.7 LED indicator ON/OFF

This FT2 camera does not have an indicator light. This does not apply to your camera, please ignore it.



9.5.2.3 Local application

You can do the settings for Local account. RTSP.



9.5.2.3.1 Local account

If you have a NVR device or some 3rd party software, you can set it up here. (Username, Password), Tap


to show and check your password.



9.5.2.3.2 RTSP

You can use the URL to play live streams through a RTSP player on the same network as the camera.






Example	rtsp://username:Password@Camera lp address:port/avstream/channel=1/stream=*.sdp
【2K】	rtsp://admin:admin123@192.168.0.94:554/avstream/channel=1/stream=0.sdp
[SD]	rtsp://admin:admin123@192.168.0.94:554/avstream/channel=1/stream=1.sdp


9.5.2.4 Privacy settings

You can do the settings for Privacy settings, Timed OFF schedule, Device microphone.




9.5.2.4.1 Camera timed OFF

You can set a schedule or 24/7 to turn off your camera. When it is OFF, the camera will not be viewed and record, send the alert, etc. However, you can replay previously recorded videos/photos.



9.5.2.4.2 Timed OFF schedule

You can do the settings here, either 24/7 or schedule 1, schedule 2.



You have 3 options: 24/7; Schedule 1; Schedule 2.




24/7 Mode




Schedule 1


Enable Schedule 1




1. Select and confirm start times and tap ok




3. Select and confirm repeat dates and tap ok



2. Select and confirm end times and tap ok



4. Tap \leftarrow , shows your Schedule 1 times and dates.



9.5.2.4.3 Device microphone

If you turn it off, the microphone is disabled.




9.5.2.5 Device time zone

You can set the correct time zone for your camera. If you and your camera are in different time zones, the camera will send you real-time alert notification according to your setting.

Note: Time zone is an important setting that will take effect immediately after the modification, but some of the recordings before may be displayed wrongly in calendar, including alerts, cloud storage, local storage recordings.






9.5.3. Home protection settings

You can do the settings of Motion detection, Motion alert, Cloud storage, Memory card storage and Light and night vision.



9.5.3.1 Motion detection

You can do the Motion detection settings.



9.5.3.1.1 Detection area

You can set your motion detection area here.

Tap > to enter the setting page. The default setting is Full area.






Drag the green box to set your detection area, tap 🗲 to complete the setting.




9.5.3.1.2 Sensitivity level

You can set the Alert Sensitivity level here. There are 5 options: Low, Middle Low, Normal, Middle high, and High.



9.5.3.2 Motion alert

If you enable motion alert, the camera will trigger the alarm when there is any activity. And you can set the alarm time. For example, all-day schedule, or at most 2customizing schedule time within 24 hours.



CAUTION: If you would like to enable motion alert, please turn it on and you have to schedule the alert time, or simply 24/7.

9.5.3.2.1 Enable

Enable Motion alert.



9.5.3.2.2 Schedule

You can set Schedule Mode to 24H or the other 2 Schedules here




24/7 Mode




Schedule 1

Enable Schedule 1




Select and confirm start times and tap ok


Select and confirm end times and tap ok




Select and confirm repeat dates and tap ok



Tap \leftarrow , shows your Schedule 1 times and dates.






9.5.3.2.3 Identify and push

You have 2 options here:

Push all alerts without recognition Only push alerts with the enabled labels


Alert notifications will only be tagged and pushed when then abled type is identified. Mismatch type alert clips are only recorded but not pushed. You can review all alert clips in the alert list.



9.5.3.2.4 Rich notifications

If you enable it, you can see a quick preview of the alert in the notification when a motion alert occurs, without having to open the App.

Add the device to the available enhancement package to enable it. Please refer to 11. Cloud Page.




9.5.3.3 Cloud storage


For more instructions, please refer to 11. Cloud Page.

9.5.3.4 Memory card storage

You can insert a Micro SD card (8GB-256GB) in the camera. If you enable Motion alert, it will save alarm video on the memory card when there's any activity. You can set schedule memory card recording time.

Note: Please insert and unplug the SD card after the device is powered off.





CAUTION:

If you would like to enable motion alert, please turn it on and you have to make your alert schedule.

9.5.3.4.1 Memory card storage

Enable Memory card storage.

Memory card storage

9.5.3.4.2 Schedule

You can set Schedule Mode to 24H or the other 2 schedule here.




24/7 Mode




Schedule 1

Enable Schedule 1




Select and confirm start times and tap ok


Select and confirm end times and tap ok




Select and confirm repeat dates and tap ok



Tap \leftarrow , shows your Schedule 1 times and dates.






Tips: The settings for Schedule 2 will be the same as Schedule 1.


9.5.3.4.3 Storage mode

Storage mode Motion detection recording It only records when a motion is detected




9.5.3.4.4 Storage space

You can check the storage space of the memory card and do the settings for 'When the space is full...", either "Stop storage" or "Overwrite the earliest files".




9.5.3.4.5 Format the memory card

You can format the SD card here.



Tap ok to complete the formatting.



9.5.3.5 Light and night vision

You can set the best mode for you. We recommend "Intelligent Light" mode.

Auto infrared mode

When the light is poor, the infrared lights are automatically used to fill the light to enter the night vision mode. The image is black and white.

Intelligent light


Auto infrared mode works by default, but when amotion occurs at night, the white lights automatically light up and the image becomes color.

Full color night

White light automatically lights up at night, the image remains in color and it automatically goes out during the day.


All off mode

"All off mode", for applications where the light is always bright and the image remains color at all times.




9.5.4. Device maintenance

You can do the settings of




9.5.4.1. Network

Click on Network to reconnect the camera to the Wi-Fi. Please reset the camera before the reconnection.



9.5.4.2. Device management

You can restart camera or restore the camera to factory default. Note: If the camera is reset to factory settings, you need to do the setup of the camera again.



9.5.4.2.1. Restart device

You can restart camera.



9.5.4.2.2. Factory reset



You can restore the camera to factory default [If the camera

is reset to factory settings, you need to do the setup of the camera again].



9.5.4.2.3. Delete the device




Once the camera is deleted, all data such as cloud storage and

alerts generated by this device will be lost, the camera will be back to factory default.



Please <u>7.</u> refer to Connect your camera to your Wi-Fi on page 22 to reconnect it.



10. Alert Page

If you turn on motion alert (How to set motion alert, please refer to Motion alert on page 54). It will save 10-sec alarm video on your Faleemi Cloud App when there is any motion. You can check the alarm videos of the last two days here for free.

If cloud service is subscribed, you can check the recent 7 days, if more than 7 days, please go to Cloud page to replay the alarm video.

ICON Definitions

Icon	Description	Icon	Description
<u></u>	Alert	•	New unread alarm events
Nov.06.2020	Calendar	•	Date of recording
	Edit	C)	Speaker On/Off
(b)	Play	(1)	Pause
	Snapshot	②	Selected
Ŵ	Delete	<u>\$</u>	Download


10.1. View alert video

Tap Calendar to show highlighted (green dot •) date of recording.


Tap to play alert video in a new page, the


date of the playing video is green. Tap in other videos, it will play this video. Tap Calendar to show highlighted (green dot

) date of recording. Tap on the date, it will show all the motion events of this date.



10.2. Edit alert video (delete or download alert video)






11. Cloud Page

User plays the video recorded in cloud if there is a cloud plan subscribed.

We offer the first 30-day free cloud storage experience program.

Experience Enhancement Packages Level up your devices with Enhancement Packages, which is a comprehensive subscription service that lets you save, review, download your videos in the cloud, and get more valuable features that make your devices even better.




There are 3 kinds of subscriptions:

11.1. Basic Plan

Motion recording loop for 7-days Support up to 3 devices


- Motion recording loop for 7-days
- Support up to 3 devices
- Devices can be shared with up to 5 persons
- All alerts within 7 days come with 10s video
- Alert notification with a quick image
- Time shifting, quickly review during live



11.2. Extended Plan

Motion recording loop for 15-days Support up to 5 devices

- Motion recording loop for 15-days
- Support up to 5 devices
- Devices can be shared with up to 7 persons
- All alerts within 7 days come with 10s video
- Alert notification with a quick image
- Time shifting, quickly review during live






11.3. Pro Plan

Motion recording loop for 30-days Support up to 7 devices


- Motion recording loop for 30-days
- Support up to 7devices
- Devices can be shared with up to 9 persons
- All alerts within 7 days come with 10s video
- Alert notification with a quick image
- Time shifting, quickly review during live



11.4. Plan comparison


Erro	Basic		Extended	Pro	
rree	Standard	Plus	Al	Extended	Pro
N/A	Up to 3 devices	Only for 1 device	Only for 1 device	Up to 5 devices	Up to 7 devices
/	/	/	/	/	/
/	/	/	/	/	/
/	/	/	/		/
Up to 3 persons	Up to 5 persons	Up to 5 persons	Up to 5 persons	Up to 7 persons	Up to 9 persons
10s videos for 2 days, images for 7 days	10s videos for 7 days	10s videos for 7 days	10s videos for 7 days	10s videos for 7 days	10s videos for 7 days
	/	/	/	/	/
	Motion detection recording, history for 7 days	Continuous recording, history for 7 days.	Motion detection recording, history for 7 days	Motion detection recording, history for 15 days	Motion detection recording history for 30 days
	/	/	/	/	/
			/		
			/		
			/		
			,		
	V Up to 3 persons 10s videos for 2 days,	N/A Up to 3 devices V V Up to 3 persons Up to 5 persons 10s videos for 2 days, images for 7 days Motion detection recording,	Free Standard Plus N/A Up to 3 devices Only for 1 device V V V Up to 3 persons Up to 5 persons Up to 5 persons 10s videos for 7 days images for 7 days Motion detection recording, Continuous recording,	Free Standard Plus AI N/A Up to 3 devices Only for 1 device I device Only for 1 device	Free Standard Plus AI Extended N/A Up to 3 devices Only for 1 device Only for 1 device Up to 5 devices V V V V V V Up to 3 persons Up to 5 persons Up to 7 persons Up to 7 persons 10s videos for 7 days images for 7 days Motion detection recording, history for 7 days history for 7 days Notion detection recording, history for 7 days Notion detection recording.

11.5. Cloud devices management





11.5.1 Add recording devices

- 1. Tap + add the device to the plan, Select the device you want to add.
- 2. After the camera is added, Tap Go to settings.



3. You can do the settings for Cloud storage, Shared users, Motion alert, Remove the device from this plan, etc.





11.5.2. Camera settings in the enhancement package

11.5.2.1. Cloud storage time settings

Tap > to do the setting



Turn on Enabled, and do Schedule settings




Turn on 24/7 or Schedule 1 or Schedule 2.



11.5.2.2. Shared users

Tap > to do the settings

You can activate/deactivate shared accounts on demand with in the maximum number of shares, The maximum number can be expanded by subscribing to an enhancement package.



1/5 >

11.5.2.3. Motion alert

Shared users

package.

Tap > to do the settings

Identify and push Push all alerts without recognition Only push alerts with the enabled labels


Alert notifications will only be tagged and pushed when then abled type is identified. Mismatch type alert clips are only recorded but not pushed. You can review all alert clips in the alert list.

Rich notifications

If you enable it, you can see a quick preview of the alert in the notification when a motion alert occurs, without having to open the App.

Note: Enabling it may slightly increase your phone's traffic.






11.5.2.4. Remove the device from this plan

Tap to delete the device

Remove the device from this plan


11.6. Cloud Replay

Tap \mathfrak{D} to replay. For more instructions, please refer to Replay.



12. Me Page

Information about Faleemi Cloud account.



ICON Definitions

lcon	Features	Description
•	Local Video	The alarm videos downloaded from the SD card or Faleemi Cloud App and the video recorded manually can be view here. And you can save them to your mobile album.
	Local Photo	The snapped photos can be view here. And you can also download the photos to your mobile album.
\checkmark	Message	System Messages.
ø	Account security	Set Touch ID or Change Account Password.

0	General settings	Set the Faleemi Cloud app Language and Message notification.
\circ	Contact us	You can contact Faleemi by clicking on Contact us.
②	FAQ	Troubleshooting Frequently Asked Questions
Ų	Diagnose	You can do a network diagnostic here and contact us
4	About	You can check the App version.
ightharpoons	Sign out	Sign out the Faleemi account.

12.1. Album & Message



12.1.1. Local Video


The alarm videos downloaded from the SD card or Faleemi Cloud App and the video recorded manually can be view here.


And you can play video, save, share or delete them to your album.

Tips:










12.1.2. Local image


The snapped photos can be view here. And you can also download the photos to your album. And you can view photos, save, share or delete them to your album.

Tips:










12.1.3. Download

It shows the status of the video/photo download.



12.1.4. Message


The push notification will be listed in System Messages



12.2. Account security




Set Touch ID or Change Account Password, tap > go to setting page.



12.2.1. Quick login

There are three quick login methods here (Auto login, Gesture login, Touch ID), please set them up according to your needs.



12.2.1.1 Auto login


There is no need to verify the automatic login when logging in to the app



12.2.1.2 Gesture login

Tap Gesture login, Please draw an unlock pattern, And reconfirm, Tap ← done.





12.2.1.3 Touch ID

When you log in to the app, you will be automatically logged in using Touch ID.




12.2.2. Change Password

You can change your password here. Please follow below screenshots to do it.




Your password must be 8-16 characters, and include at least 3 categories of the following: Digits, Uppercase characters, Lowercase characters, Special characters.

1. Tap >



2. Enter your old password and new password, (tap

to check and make sure your password is correct). Please record your new password and tap OK.





3. It will jump back to the sign in page and please use the new password to login.

13.3.2.1. Forgot password? (To reset your account and password):

If you forget your password, please follow below instruction to reset your password. (Email)

1. You can find "Forgot password" in sign in page, and tap it





2. Enter your Email and new password, (tap to show your password up and check it to make sure it is correct). Please record your new password and tap Reset.



3. It will send you a verification code email.

12.2.3. Country/region

It shows your country where you register your account.

Country/region **United States**

12.2.4. Email

This email is your account user name.




12.2.5. Delete Account



You can delete your account here.


You MUST first delete all devices under your account, cancel your cloud subscriptions that are activated.



12.3. General settings



Set the Faleemi Cloud app Language and Message notification.




12.3.1. Language

You can change the Faleemi Cloud App Language (16 languages) here.

* By default, the language that displays when you log in to the Faleemi Cloud app interface is set to Auto.





13.3.2. Reminder of cellular data

You can do the setting for Reminder of using cellular here.





13.3.3. Notification settings

You can do the setting for Message notification (App notification, Alert notification, System notification, Marketing notification, Notification tone follow system) here.

You can modify in your phone

"Settings - Notification - Faleemi Cloud".






13.3.4. Enable hard decoding


Enable the phone's hard decoding can usually improve live performance, but it is possible that there may be abnormal conditions during live due to compatibility. Please select the option based on the actual effect.



12.4. Contact us




12.5. FAQ




12.6. Diagnose



You can get a diagnosis here, Please make sure your phone is connected to the same Wi-Fi as the camera when you do the diagnostics.






12.7. About



You can check the **App version**, Version update, Terms of Use, Privacy Policy.



12.8. Sign out



13. Frequently Asked Questions (FAQ)


1. Which App does this camera use?

It uses "Faleemi Cloud" App and does not support "Faleemi" App.

2. How to reset your camera (restore to factory default)?

1.Unplug the camera, then plug it back in, and wait for the camera to boot up. 2. Open the waterproof rubber gasket on the bottom of the camera, press and hold the reset button with a thimble for about 5 seconds, and release it when you hear a "beep".


- 3. After resetting, the camera will restart, and when the auto-rotation check stops, close the waterproof rubber gasket.
- 4. You can start the connection when you hear a "beep-beep" sound.



2. How to install memory card?

Please do so when the power is off, Please insert the Micro SD card as what shows above. Suggest using an 8G-256G Micro SDHC/SDXC.

(* Micro SD, Micro SDHC/SDXC text and logo are the trademark of SD-3C, LLC.)



3. Cannot receive the activated email when you sign up a new account or change account password on App.

- a. The email might be deemed as junk email. Please kindly check it in spam.
- b. If there is no activated email in spam. Please add "mail.ajcloud.net" into the white list in the mailbox and then tap "Re-send email".

c. Please send the email to: support@faleemi.com.

4. The memory card cannot be recognized by camera.

- a. Please kindly check if the camera inserted correctly.
- b. Please try to reboot your camera then check it again.
- c. Please put the memory card on your computer and check if it's recognized and also format it to FAT32 format on computer then check it on camera.
- d. If your computer doesn't recognize it, replace it with another SD card.

5. What kind of memory card that the cameras are compatible with?

The cameras support memory card capacity of 8G/16G/32G/64G/128G/256G. We usually would like to suggest 64G of Kingston, SanDisk and Samsung.

6. Why aren't the recorded motion alerts notifying my phone.

Please go to Camera Settings page to check that if you turned on motion Alert and go to [Me] → [General settings] → [Message] notification to check that if you allowed the Faleemi Cloud app to send you notification.

7. I don't have Wi-Fi at my house. Would this camera work without it?

No, the camera does not work without Wi-Fi.

8. Can the app be used on two devices at the same time? Like my iPhone and my family's iPhone.

Yes, but you have to invite your family to view the feed of your camera. For more information, please kindly check the "Invite family members". Then you and your family should able to view the camera on two devices at the same time.

9. Can you invite someone to the app, and then remove them afterward.

Yes, you can add the app to other phones and remove when needed. You can do it on Invite family member Page.

10. Do I have to subscribe cloud service to use the camera?

No. Cloud service is optional. Users can use the camera without subscribing cloud storage. You can use Micro SD card for recording also.

11. Does the camera need to connect the power supply?

Yes, it needs to be plugged into an outlet for continuous power.

12. How can I get after-sales service?

You can send us a message on Faleemi website or send an email to our support (support@faleemi.com) or call our support team. You will find the contact information on Faleemi website or in the included manual.

© Faleemi Technologies Ltd or its affiliates. All rights reserved.

No part of this publication may be reproduced or transmitted in any form or by any means or used to make any derivative work (such as translation, transformation, or adaptation) without written permission from Faleemi Technologies Ltd ("Faleemi"). Faleemi reserves the right to revise this publication and to make changes in content from time to time without obligation on the part of Faleemi to provide notification of such revision or change.

Faleemi provides this guide without warranty of any kind, implied or expressed, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Faleemi may make improvements or changes in the product(s) described in this manual at any time.

The capabilities, system requirements and/or compatibility with third-party products described herein are subject to change without notice.